UNITONE

USER MANUAL

FOR VIDEO INTERCOM & ALARM SYSTEM 3000

SYSTEM FEATURES:

1. **RECEIVE CALLS FROM THE BUILDING CALL PANEL**

2. **CALLING THE CONCIERGE**

3. **VIEWS IN APARTMENT UNIT FROM THREE OTHER CAMERAS**

4. **TENANT INFORMATION STORED IN THE COMPUTER**

5. **MESSAGE SERVICE**

6. **COMPLETE INTRUSION ALARM SYSTEM**

   A) **HOME MODE**

   B) **AWAY MODE**

HOW TO USE YOUR APARTMENT VIDEO UNIT:

1. *RECEIVING CALLS FROM THE BUILDING CALL PANEL*

As soon as the Visitor calls you, you will hear a chime, and see a view of the lobby on your monitor. You can either:

- Pick up the handset and talk to the visitor, **or**
- Don't answer, the visitor will not know if you are at home.
- To command the opening of the building door, press the "key" button while the handset is off the hook.

NOTE: The communication between the lobby panel and the apartment unit is preset for a period of time.

2. *CALLING THE CONCIERGE*

- Pick up the handset, listen for the dial tone.
- Press "*" on your keypad.

3. *VIEWS IN APARTMENT UNIT FROM THREE OTHER CAMERAS*

- In addition to the lobby view, residents can obtain additional views from the three other cameras by pressing any one of the three "eye" buttons.

NOTE: If the view is interrupted, a flashing yellow light will indicate that a visitor has just called an apartment, and therefore has priority.

4. *TENANT INFORMATION STORED IN COMPUTER*

- You can give important information to the Concierge, where it will be stored in the computer and used in an emergency.
- You can also provide useful information about frequent visitors, domestic help, your pets, etc. in order to receive better security and services.

5. *MESSAGE SERVICE*

- A green flashing light on your unit keypad indicates there's a message for you.
- When you call the Concierge to receive your message, you can ask him/her to delete or keep the message. If you ask him/her to delete the message, the green light will turn off.

6. *COMPLETE INTRUSION ALARM SYSTEM*

Setting or Changing the Security Code

- Call the Concierge, and ask for the code change authorization.
- He/She will send you a short "BEEP" over the receiver.
- Enter your 4-digit code and then press the "*" button before hanging up the handset. No one (not even the Concierge) will know your code. You can change this code as often as desired following the above procedure.

A) *Away Mode*

How to Activate:

- Make sure the front door is closed.
- Press "ARM" button, the red light will illuminate.
- Leave apartment within 30 seconds.

How to Deactivate:

- Upon your return, when you open the door, beeps from the unit will remind you to enter your code which should be punched in within 30 seconds. (Press your 4-digit code and the "*" button). And the red light will be turned "Off".
- If someone breaks into your apartment, and does not punch in the code within 30 seconds, your unit will sound an alarm pattern for a preset period of time, and alert the concierge.

B) *Home Mode*

- Press "ARM" button twice (or repeatedly, if necessary) and red light will flash.
- Should someone break in, the alarm will sound immediately for a preset period of time (there is no 30 second delay). (To turn off the alarm, press your 4-digit code and the "*" button).